




Ford 5.0 EFI Harness
Installation Manual
For Classic Fords & Mustangs
and Early Broncos



Part Number: TDZ-75SD / BRONCO-75SD

Ron Francis Wiring &
The Detail Zone
200 Keystone Rd.
Chester, PA 19013
800-292-1940
www.ronfrancis.com


Pre-Installation Notes:

- Make sure that all the components you have are compatible before installing them.
- Intakes are fairly interchangeable, make sure the upper and lower intakes match, and the lower intake has a port for the Air Charge Temp sensor (ACT) sensor.
- The fuel rail will dictate which side the intake faces, make sure you have the correct one. This harness is set up for a drivers side facing intake when in stock form.
- This harness does not include provisions for emissions and is not intended for installation on emission controlled vehicles.
- The distributor should be specific for your engine (5.0L / 5.8L) and have the TFI Ignition Module mounted onto the side.
- Ford EFI systems were not intended for use with long tube headers. The Oxygen Sensors are less accurate (due to dissipated exhaust heat) when mounted further down stream from the cylinder head. However this harness will work with all exhaust systems.
- Always disconnect the battery when working on vehicles fuel or electrical systems. Any electrical spikes can damage parts of the fuel injection system.
- Use extreme caution if and when welding on any vehicle with a fuel injection system.

Pre-Installation Instructions:

Install the lower intake, fuel injectors, and fuel rail on the engine if not already installed. Remove the upper intake if it is installed and install stock fuel pressure regulator. Plumb fuel lines with appropriately rated line. Use caution when working on fuel system, 40-100PSI can be held within system. To release fuel pressure, remove fuse or relay to fuel pumps, then start engine and allow it to stall. Crank starter for several seconds to insure all pressure has been released.

Before installation spread out the harness in a well lighted open area to identify all the connectors and become familiar with what will need to be done.



- 1) Computer Connector
- 2) Inertia Fuel Cutoff Switch
- 3) Transmission Controller Connection
- 4) Tachometer & Engine Light Connections
- 5) Transmission ID Plugs
- 6) Self-Test Connectors
- 7) Barometric Pressure Sensor
- 8) Mass Air Sensor (NOT USED)
- 9) Battery Connections

- 10) Throttle Position Sensor
- 11) Idle Air Bypass
- 12) Engine Coolant Temp Sensor
- 13) Ground
- 14) Injectors
- 15) Air Charge Temp Sensor
- 16) TFI Distributor Connector
- 17) SPOUT Connector
- 18) Temp Gauge Sender

- 19) Oil PSI Gauge Sender
- 20) Ignition Coil Plug
- 21) R & L Oxygen Sensors
- 22) Body Connection
- 23) Vehicle Speed Sensor
- 24) Fuel Pump Power
- 25) AC Compressor Wire
- 26) Alternator Connection


Note: On this speed density (non-mass air flow version) the Throttle Position Sensor and Idle Air Bypass may be located on the other side of the harness.

Installation Instructions:

- 1** Lay the harness into the engine compartment with the relay and fuse blocks on the passenger side.
- 2** Remove the last bolt holding the lower intake down on the passenger side. Install #13 engine ground and torque the bolt back down to specifications. This is extremely important and should be the first connections made!
- 3** Install all eight fuel injector connectors starting with cylinder #1 and working your way around. Connecting the injectors now helps get the majority of the harness into position.
- 4** Connect #12 Engine Coolant Temp sensor, #15 Air Charge Temp sensor, and #18 Temp Gauge sender before moving away from the intake.
- 5** Connect #19 Oil PSI Gauge sender. Route Oil PSI Gauge sender wire carefully away from hot exhaust headers.
- 6** Route #21 Right & Left O2 sensors, #23 Vehicle Speed sensor, and #24 Fuel Pump power wires down to their locations under vehicle. Route #23 Vehicle Speed sensor and #24 Fuel Pump power connectors along the left frame rail. Keep them away from hot exhaust moving parts like driveshaft.
- 7** Weld exhaust bungs into both sides of the exhaust approximately 9-12 inches from the last cylinder head exhaust port or 3" from the collector. Clean any debris from oxygen sensor ports and threads.
 - a)** Use a small amount of anti-seize on the threads when installing Oxygen Sensors. Use SG23 Oxygen sensors with short headers. Use SG40 Oxygen Sensors with long tube headers.
 - b)** Connect #21, oxygen sensors to their connectors and attach any free harness to the firewall or frame to keep them from falling against the exhaust.
- 8** Install Vehicle Speed Sensor between the transmission and speedometer cable. Route #23 Vehicle Speed Sensor connector along the left frame rail and plug into the Vehicle Speed Sensor.
- 9** #24 is a 14Ga pink wire to power your fuel pump(s); you will need to splice this wire if you are using 2 fuel pumps that are not mounted together. Make sure the fuel pump(s) are well grounded.
- 10** Carefully route #20 Ignition Coil connector along firewall and fender to the coil. Keep Radio power wires and antenna cables away from Ignition Coil to prevent future distortion or interference.

11 For this harness to work you must connect it to the body harness so it turns on with the dash key. #22 is responsible for connecting your engine temp and oil PSI gauges to the engine and your ignition key to the harness

a) If you have the original Ford body harness find the engine connector at the firewall above the drivers side valve cover. This is a 3 pin connector is at the firewall next to the brake master cylinder.



Use the supplied adaptor to connect the EFI harness to the Body harness:



b) If you have an aftermarket body harness or your factory body harness is in poor condition, connect the EFI harness to the body harness with the 3ft supplied adaptor. Connect the bare wires to the Body harness as follows:

IGNITION RUN ENGINE TEMP GAUGE OIL PSI GAUGE

THE DETAIL ZONE Harness	Orange	Blue	White
Original Ford Harness	Red / Green	Red / White	White / Red
Centech Body Harness	Dark Blue	Blue	Orange
Painless Harness	Blue / White	Blue	Orange
Digital Dash	-	WATER	OIL

12 After connecting #22 to the body harness you can install the upper intake plenum onto the lower intake and install the throttle body to the upper intake. Now would also be a good time to finish the vacuum system.


13 Connect #10 Throttle Position sensor and #11 Idle Air Bypass before leaving the upper intake.

- 14** Locate where in the firewall you will route the computer plug and other under dash connectors. This harness was designed for the hole to be cut near the fender as shown below.



Mustang Firewall Shown

Cut a 1.5" X 2.75" oval hole, using the template provided below. Use a 1.5" hole saw, and then connect the 2 round holes to make an oval. Mount the computer and feed the under dash section of the harness into place. Once harness is in place, install the supplied grommet.



- 15** Route the passenger side of the harness along the firewall and fender. Mount the Relay & Fuse blocks securely to the inner fender. Mount them upright, if the relays can retain water they will fail prematurely.
- 16** Mount the Barometric Pressure sensor to the firewall or inner fender and connect it to the harness at #7.

- 17** Locate #5 the transmission identification terminals near the Self-Test connectors. You need to plug the male terminal into one of the female terminals, depending on which computer type you are using. The male plug is labeled "TRANS" and the female plugs are labeled "AUTO" & "MAN." You need to identify your computer as an automatic or manual transmission computer by its sticker. If you are unsure which computer you have your local Ford dealer should be able to help.
- a)** If your computer is for an automatic transmission; connect "TRANS" plug to the Black "AUTO" plug.
 - b)** If your computer is for a manual transmission; connect "TRANS" plug to the Gray "MAN" plug.
- 18** Install #8 the Mass Air Flow sensor, air filter and air tubes. Connect the MAF to the harness. NOT USED IN YOUR APPLICATION.
- 19** Before you install the distributor make sure the engine is at TDC for cylinder one, and you have mounted the TFI to the side of the distributor. Drop in the distributor so the rotor is aligned with the 1 molded into the cap. Make sure there is enough room to rotate the distributor in the block 1/8th turn. You will need to rotate it to set the base timing of 10° BTDC.
Connect #16 to the TFI on the Distributor to the harness and make sure that #17 SPOUT connector is connected firmly. Only disconnect the SPOUT to check and set the base timing.
- 20** It is advised that you use an inertia switch to turn off the fuel pump(s) in the event of a crash. Under the dash is connector #2 for the Inertia Fuel Cutoff Switch. Mount the Inertia Switch completely upright and connect it to the harness. Mounting the switch any other way or bypassing this switch can cause risk or fire or loss of life. Before continuing, tap the switch until the button on top pops up and reset it. This will confirm its action and get you familiar with how it works.
- 21** #4 is 3 wires under the dash with the computers 60-pin connector, one of them is green and marked "TACH."
- a)** If you have a tachometer hook the green "TACH" wire to the input terminal marked "S" on the gauge.
 - b)** If you have a digital dash connect the green wire marked "TACH" to the dash input terminal marked "TACH."
Do not leave bare wires open under the dash if you don't have a tachometer!

- 22** #4 is 3 wires under the dash with the computers 60-pin connector, one is red and marked "MIL PWR"; another is tan and marked "MIL."
- a) If you have a simple light, connect the wires to the light, it does not matter which wire is connected to which side of the light. Feed the wires and light back through the dash and press it into the hole.
 - b) If you have a digital dash connect the tan wire marked "MIL" to the dash input terminal marked "CHECK." Seal off the red "MIL PWR" wire.
Do not leave bare wires open under the dash if you skip the check engine light!
- 23** Under the dash with the 60-pin computer connector is a round connector #3. This connector is ONLY for Baumann Electronic Transmission Controllers. If you do not have an electronically controlled transmission, leave #3 alone.
- a) If you have a Baumann Electronic Transmission Controller that came with the transmission harness, it will plug into this port.
 - b) If you have an older Baumann Controller that did not come with a transmission harness, please contact Baumann for a pigtail or new harness and instructions on how to connect to this EFI harness.
- 24** Connector #1 is for the computer, make sure the computer pins are not bent or damaged. Then connect the harness with a 10mm socket. DO NOT use air or power tools to install this connector!
- 25** Next to the Fuse & Relay blocks are a large 10Ga red wire and a thinner 18Ga purple wire.
- a) Connect the 10Ga Red 3/8" terminal to Battery Positive or the starter solenoid.
 - b) Connect the 18Ga Purple 1/8" terminal to a start signal on the starter solenoid.
- 26** #26 is ignition power wire for your alternator. It is not meant to charge the vehicle, but to turn the alternator ON when you turn the key to RUN. Consult your alternator installation manual for further instructions.
- 27** #25 is a wire provided for you AC compressor. Connect the bare wire marked "AC" near the compressor to the positive side of the connector. Connect the bare wire marked "AC" near the relays to the compressor power wire from the vehicle.
- 28** Please take the time to run a Self-Test at #6 prior to starting the engine. This will clue you in to any connections you missed, and give you a base line to compare future tests against.

29 If this is the first fuel injection installation on this vehicle run the fuel pump(s) for 30-60 seconds to create fuel pressure for the injectors. To do this, ground the terminal on the end of the larger Self-Test connector marked ECM 22->VIP.

Codes 33, 44, 81, 82, 84, 85 and 94 are what's called "soft" codes and do not affect the engine fuel or spark programming. These codes will set due to the smog solenoids CANP, EGR, TAB and TAD being removed. Soft codes harmlessly stay dormant in the computer. Their purpose is to help aid in the repair of those systems. Soft codes will not turn on the Check Engine Light.

There is a resistor pack already installed in this harness for the EGR Valve Position Sensor. No other resistors are required.

USING THE CHECK ENGINE LIGHT

The check engine light performs just the same as it would in any newer car, when the key is turned on (engine not running) the light will stay on till the engine starts.

When the check engine light comes on during engine operation, it is an indication of a fault in the system. It will be necessary to have the computer perform a self test diagnostic procedure. The self test is divided into three specialized tests:

KEY ON ENGINE OFF SELF TEST: For this test the fault must be present at the time of testing. For intermittent problems refer to continuous memory codes.


ENGINE RUNNING SELF TEST: The sensors are checked under operating conditions and at normal operating temperatures.

CONTINUOUS MEMORY CODES: These codes are issued as a result of information stored while the vehicle was in normal operation.

READING THE CHECK ENGINE LIGHT: A service code is reported by a flash of the check engine light. All service codes are two digit numbers, such as 2-3. The light will display two flashes, then, after a two second pause, the light will flash three times. All self test codes (if any) will be displayed and then a delay of six seconds, a single half second separator flash and another six second delay and then the continuous memory codes will be flashed.

If the light remains on after the engine is running then follow the procedures below to have the check engine light flash trouble codes.

Locate the V.I.P self test connectors and connect a jumper wire between the grey wire (VIP->CTS SPL) located in the large VIP connector and the tan wire (ECM 48->VIP) located in the single connector as shown in the drawing below.



Trouble Codes


- 11 System PASS
- 12 High RPM
- 13 Low RPM
- 14 PIP circuit failure
- 15 ECG memory failure
- 16 RPM low for EGO test
- 18 SPOUT /IDM circuit failure
- 19 ECG internal voltage failure
- 21 ECT out of test range
- 22 MAP /BP out of test range
- 23 TP out of test range
- 24 ACT of test range
- 26 MAF out of test range
- 29 Vehicle speed sensor problem
- 31 EVP voltage below minimum
- 32 EVP voltage below closed limit
- 33 EGR valve opening not detected
- 34 EVP voltage above closed limit
- 35 EVP voltage above maximum
- 41 HEGO (R) sensor lean or defective
- 42 HEGO (R) sensor rich
- 44 Thermactor air system defective (R)
- 45 Thermactor air upstream during self test
- 46 Thermactor air not bypassed during self test
- 51 ECT indicated -40NF/open circuit
- 53 TP circuit above maximum voltage
- 54 ACT indicated -40NF/circuit open
- 56 MAF circuit above max voltage
- 61 ECT indicated 254NF/circuit grounded
- 63 TP circuit below minimum voltage
- 64 ACT indicated 254NF/circuit grounded
- 66 MAF circuit below minimum voltage
- 67 Neutral drive switch circuit open
- 74 Brake on/off circuit open during self test
- 75 Brake on/off circuit closed/ ECG input open
- 77 Brief WOT not sensed during self test
- 79 A/C on defrost on during self test
- 81 Air management 2 circuit failure
- 82 Air management 1 circuit failure
- 84 EGR Vacuum Regulator circuit failure
- 85 Canister purge circuit failure
- 87 Fuel pump primary circuit failure
- 91 HEGO (L) sensor lean or defective
- 92 HEGO (L) sensor rich
- 94 Thermactor air system inoperative (L)
- 95 Fuel pump secondary circuit failure
- 96 Fuel pump secondary circuit failure
- 98 Hard fault present FMEM mode

No codes = unable to indicate self test

Code not listed = Not applicable to this engine

The following diagram shows some of the sensor locations on Ford 5.0 engines. The sensors not shown are mounted remote (off the engine) on the stock vehicle application. Your installation may require these items not to be mounted in the same location as on a factory installation. The numbers before the sensor names correspond to the numbers shown in the drawing.

- 1) Air Charge Temperature Sensor
- 2) Shorting Plug
- 3) TFI Ignition Module
- 4) Coolant Temperature Sensor
- 5) Idle Speed Control
- 6) Mass Air Flow Sensor (NOT USED IN YOUR APPLICATION)
- 7) Throttle Position Sensor
- 8) Right O2 Sensor
- 9) EGR Valve Position Sensor
- 10) Injectors
- 11) Left O2 Sensor



Fuse and Relay Key	
Fuse and Relay Designation	Fuse Size
Oxygen Sensors (Relay A)	15 AMP
Fuel Pump (Relay B)	20 AMP
Coil & TFI Module (Relay C)	15 AMP
ECM, Injectors, IAC (Relay D)	20 AMP

Tech Line Number: 610-485-1981

Warranty Information

All Detail Zone Performance products are warranted for 1 year from purchase date. There are no other representations, warranties or conditions expressed or implied, statutory or otherwise except those herein contained. Warranty does not cover any defect which is the result of improper installation or modification of the system or any of its components by purchaser.

Detail Zone Performance Inc, its dealers or agents will not be liable, in any way, for any damage, loss, injury or other claims, resulting from the use or misuse, or inability to use any of our products. Purchaser and/or user, assumes liability of any kind connected with the use and/or application of our products.